

## Secure Seal Universal Outer Adaptor UNIBAO

STEP 1: Add a bead of Viton caulking all around the boiler outlet



STEP 2: Install the inner wall over the boiler outlet and slightly tighten the first inner collar to hold the piece in place. Make sure the joint is on top. Do not tighten the collar too much at this time.



STEP 3: Place the two remaining inner collar over the inner wall and insert the male end of a Secure Seal part inside the inner collar. Make sure the inner wall is well positioned over the O-ring before tightening the collar. Position the draw band and tighten the three collars firmly.



STEP 4: Fill all the gaps with Viton caulking



STEP 5: Insert the exterior seal inside the outer wall of the Secure Seal part and tighten the screw. Install the outer collar and tighten to finish installation



**You are done!**